



WATER TECHNOLOGY

## Avensys

### Exposed Single Thermostat Mixing Valve



34 033




34 034

### Installation Instructions and Operating Guide

Please leave this document with the user after finishing installation!


Table Of Contents




1

Installation Dimensions (mm)

34 033




34 034



2

Spare Parts



3

4

## Index

<b>Table Of Contents</b> .....	1
<b>Installation Dimensions</b> .....	2
<b>Spare Parts Drawing</b> .....	3 + 4
<b>Spare Parts List</b> .....	5
<b>Technical Data</b> .....	6
<b>Installation</b> .....	7
Exposed Installation .....	7
Pipe And Shower Hose Connection ..	9
Adjustment .....	10
<b>Maintenance</b> .....	11
<b>Care</b> .....	13
<b>Trouble Shooting</b> .....	13
<b>Guarantee</b> .....	15

### Dear Customer,

Thank you for choosing a GROHE product. Please follow these instructions carefully and you will enjoy many years of reliable service from this fitting.

## Spare Parts

No.	Description	Cat.-No.	Pack- ing unit	No.	Description	Cat.-No.	Pack- ing unit
1	Handle complete	47 591	1	9.4	Filter	06 768	5
1.1	Cap	00 090	1	9.5	Escutcheon	00 197	2
1.2	Fixing set	47 592	1	10	Handshower	28 216	1
2	Cover ring	00 565	1	10.1	Adjustment ring	45 794	1
3	Stop ring	47 593	1	10.2	Filter	07 002	2
4	Control unit	47 600	1	11	Shower rail	28 666	1
5	Wax element	00 798	1	11.1	Sliding shower holder	07 659	1
6	Slider	07 587	1	11.2	Shower rail holder	45 362	1
7	Seat with spring	47 594	1	11.2.1	Cover cap	45 363	1
7.1	O-ring seal	03 169	5	12	Flexible hose	28 161	1
8	Set screw M5x12	02 125	5				
9	Connection elbow	12 111	2		<b>Optional accessory</b>		
9.1	Flow limiter set	46 428	1	13	Compensation ring	45 406	1
9.2	Non-return valve	06 544	2				
9.3	O-ring seal	01 287	10				

## Technical Data

### Functioning Principle

This **Avensys** mixing valve is a thermostatic mixer with wax cartridge. Turning the handle in a counter-clockwise direction opens the water flow from cold to hot.

This product is supplied with connectors to fit  $\varnothing$  15mm pipework. Connection should be hot left, cold right as viewed from the operating position. The product is preassembled.

### Plumbing Systems

This thermostatic mixing valve is suitable for installation with:

- Gravity-fed plumbing systems with an open vented hot water cylinder
- Cold water storage cistern
- Mains pressure unvented and instantaneous thermal hot water storage systems
- Multi-point gas water heaters
- Combination boilers with a modulating hot water output

### Supply Pipework

Ensure the supply pipework is thoroughly flushed before installing the mixing valve. GROHE recommends installing isolating valves upstream of the mixing valve for servicing purposes.

### New Water Regulations

This GROHE-product should be installed to comply with the New Water Regulations covering backflow prevention. It must also be installed in accordance with local bye-law requirements.

### Specification

- Exposed thermostatic shower mixing valve, concealed or exposed supplies
- Flow pressure
  - Low pressure 0.1 - 1 bar
  - High pressure 1 - 10 bar

- Avoid major pressure differences between hot and cold water supply:

For different supply pressures use enclosed flow limiters, see chapter "**Exposed Installation**" on page 7.

- Max. operating pressure 10 bar
- Max. test pressure 16 bar
- Mixed water flow rate without downstream resistance:

Pressure	0.1	0.2	0.3	0.4	0.5	0.6	bar
Flow rate	7.5	10.5	14	17	18.5	21	l/min

- Temperature
  - Max. (hot water inlet) 80 °C
  - Recommended (for economy) 60 °C
  - Maximum temperature is reached when the handle is rotated 270° in a counter-clockwise direction.
- Water connection hot - LH  
cold - RH

## Installation


### Exposed Installation

The thermostatic shower mixing valve can be installed in two different ways. The mixing outlet can be at the bottom for use with a handshower or at the top for use with a headshower.

If there is a pressure differences between the hot and cold water supply install attached flow limiters in the water connection elbows, see table below.

Cold Water Inlet	Warm Water Inlet	Connection	
		Cold	Warm
0.1 - 1 bar	0.1 - 1 bar	without	without
1 - 5 bar	1 - 5 bar	7 l (green)	5 l (yellow)
1.5 - 10 bar	0.1 - 0.5 bar	7 l (green)	without
	> 0.5 bar	7 l (green)	5 l (yellow)

- Screw out connection elbows (A), see Fig. [1].




- Install flow limiters (B) in accordance to table above with threaded rings (C) by using a 12mm socket spanner.


The thermostatic mixing valve is fixed to the wall via the backplate and connected to the supply pipes by a pair of elbows. The elbows are preassembled to the valve body. The valve body is fixed to the backplate by a set screw.

In case of exposed installation with supply pipes from above or below rotate inlet elbows 90° and connect to 15mm supply pipes.

1. Loosely screw on nuts (A1) with compression rings (A2), see Fig. [2].




2. Ensure that the projections of the supply pipes, (i.e. exposed beyond the wall surface) have the correct length (13 - 18mm) and distance (150mm).
3. Place the valve body (E) with the elbows and backplate (D) to the supply pipes.
4. Loosen set screw (D1), see Fig. [3].




5. Remove valve body (E) from supply pipes and hold backplate (D) in position.

## Installation


6. Mark the holes in the backplate for wall-plugs, see Fig. [4].




7. Drill the holes (6mm) for the wallplugs (F) and fit them into the wall, see Fig. [5].



8. Fix the backplate (D) with set screw (D1) on top or bottom to the wall with screws (G), see Fig. [6].



9. Slide the escutcheons (H) over the supply pipes and install filters (J), see Fig. [7].




10. Slide the valve body (E) with elbows and compression nuts loosely over the supply pipes.

**The body must touch the backplate. If not, check pipes for length again.**

11. Fix the valve body (E) to the backplate (D) by tightening set screw (D1). **Do not** use excessive force to tighten the set screw (D1).


12. Tighten the compression nuts (torque min. 20 Nm), see Fig. [8].



## Installation

### Pipe Connection

1. Close free outlet with plug (K), see Fig. [9].



2. Thread the outlet nipple (L) with the O-ring seal into the valve body outlet.

3. Insert pipe and tighten outlet nipple (L).

### Open hot and cold water supply.


Check the pipework and connections to the thermostat mixing valve for leaks.

For **reversed supplies installation** the complete mixing valve must be rotated 180°.

Therefore handle, cover ring and stop ring must be dismantled, rotated 180° and reinstalled.

### Shower Hose Connection

1. Close free outlet with plug (K), see Fig. [10].



2. Remove O-ring seal (L1).

3. Turn outlet nipple (L) 180° and fit O-ring seal (L1).

4. Thread the outlet nipple with the O-ring seal into the valve body outlet.

5. Connect flexible shower hose.

### Open hot and cold water supply.

Check the pipework and connections to the thermostat mixing valve for leaks.

For **reversed supplies installation** the complete mixing valve must be rotated 180°.

Therefore handle, cover ring and stop ring must be dismantled, rotated 180° and reinstalled.



## Installation


### Adjustment

The temperature of the outflowing water is factory set to 43 °C. A temperature adjustment is necessary if:

- The maximum water temperature measured at the outlet varies from the factory set temperature.
- After any maintenance operation on the thermostatic cartridge.

**For temperature adjustment please proceed as follows:**


1. Turn the handle counter-clockwise to fully open position and open water flow.
2. Lever out cap (M), see fig. [11].



3. Unscrew screw nut (N).
4. Pull off handle (O).
5. Remove screw (P).

**A small rinse of water drops out.**

6. Check the temperature of the outflowing water with a thermometer, see Fig. [12].




7. With a small screw driver adjust temperature to 43 °C. Turn clockwise (to reduce temperature) or counter-clockwise (to increase temperature).
8. Reinstall handle (O) in fully open position as described in Fig. [11] in reversed direction.


## Maintenance

### I. Control Unit

1. Shut off hot and cold water supply!
2. Turn the handle counter-clockwise to fully open position.
3. Lever out cap (M), see Fig. [13].



4. Unscrew screw nut (N).
5. Pull off handle (O).
6. Remove adapter (R).
7. Pull off cover ring (S) and stop ring (T).
8. Loosen set screw (D1).
9. Unscrew connections and take valve from the supplies.
10. Screw out control unit (U), see Fig. [14].




11. Take out O-ring seal (U1).

12. Screw out screw nut (P) if replacing control unit (U).
13. Take out wax element (V), slider (W) and spring (X).


Inspect and clean all parts, replace if necessary and grease with special valve grease (ref. No. 18 012).

### Reinstall control unit

1. Unscrew seat (Y) with O-ring, see Fig. [15].




2. Reinstall O-ring seal (U1).
3. Screw in control unit (U).
4. Reinstall wax element (V), slider (W) and spring (X) from behind, see Fig. [16].




5. Tighten seat (Y) in the valve body.

## Maintenance

6. Unscrew seat a half turn (180°), see Fig. [17].



7. Slide valve on the supplies, see Fig. [18]



8. Tighten set screw (D1) and compression nuts.
9. Reinstall screw (P) in control unit.
10. Push on stop ring (T) with catch (T1) on top.
11. Reinstall cover ring (S) with mark (S1) on top.
12. Push on adapter (R).
13. Close control unit by turning the adapter (R) clockwise.
14. Reinstall handle (O) in closed position.
15. Fix handle with screw nut (N) and cover with cap (M).

Readjustment is necessary after every maintenance operation on the control unit, see chapter “**Adjustment**” on page 10.

**II. Non-return valve**, see spare parts drawing on page 3, 4, and Fig. [13].

1. Same procedure as for control unit, see Fig. [13], points 1, 8 and 9.
2. Unscrew elbows, see spare parts drawing on page 3 and 4.
3. Remove threaded ring with flow limiter (9.1) if installed.
4. Take out and replace non-return valve (9.2).

Reassemble in reverse order.

Only genuine GROHE replacement parts must be used.

## Care

We want to ensure that you get long-lasting satisfaction and pleasure from your GROHE fitting. Therefore, please read the following care instructions because damage to the surface and underlying material resulting from improper treatment is not covered by our guarantee.

Do not use any abrasive sponges or scouring agents for cleaning. We also advise not to use cleaning agents containing solvent or acid, limescale removers, household vinegar and cleaning agents with acetic acid. They are aggressive to the surface and will leave

your fitting dull and scratched. As the formulations of commercially available cleaning agents frequently change, we cannot guarantee they will provide the gentle care our fitting deserves.

Clean the fitting with a little soap and a moist cloth only, then simply rinse off and wipe dry. You can avoid lime spots by drying the fitting each time it is used. If lime deposits do occur, remove them with **Grohclean** (ref. no. 18 078), our environment-friendly cleaning liquid. **Grohclean** is specially formulated to gently clean the surface of our fittings.

## Trouble Shooting

Problem	Cause	Remedy
Thermostatic valve opens through hot	Hot and cold water supplies have been connected in reverse	Rotate the thermostatic mixing valve
Range of temperature adjustment restricted	High pressure difference between hot and cold water supply	Install flow limiter see chapter <b>Exposed Installation</b>
Shower insufficiently cold or hot	Adjustment incorrectly set Hot water supply temperature too low	Refer to the instructions in chapter <b>Adjustment</b> Check hot water source temperature setting
No flow of hot or cold water	Either the hot or cold side is not fully pressurized Debris caught inside the inlet of the control unit	Replace non-return valve, refer to chapter <b>Maintenance</b> Remove mixing valve and flush out or remove any debris lodged inside the hot or cold inlets or filters
Hot water emerges to cold water supply or vice versa	Non return valves are damaged in cause of lime	Replace non-return valve, refer to chapter <b>Maintenance</b>

## Guarantee

### Guarantee declaration

Our products correspond to the valid technical and water supply standards as well as the relevant approvals requirements. We guarantee them to be free of design and production faults at the time of delivery and that with correct use and care in accordance with our printed instructions they will function reliably.

### Guarantee period

- The guarantee is valid in private homes for 5 years from the purchase date. Proof of purchase has to be provided when making a guarantee claim.
- By use in commercial or institutional applications the guarantee is valid for 1 year after first use. An extension of the guarantee up to 5 years can be achieved by showing that the product is professionally maintained each year.

To make a guarantee claim, proof of purchase or, the beginning of use is required. The guarantee period is not renewed or increased through supply of spare parts or repair during the guarantee period. The guarantee period for purchased spare parts is the same as for original products.

### Guarantee performance

- A) During the whole guarantee period we will correct all functional defects for which we are responsible (limitations see E + F).
- B) It is our option if we correct the defects by repair or replacement.
- C) During the above guarantee period we will not charge for the cost of parts, travel, working time, freight and packaging needed to effect the correction of defects.
- D) If we are not able to correct the defect we are prepared to supply a replacement product.
- E) Deliberate or careless damage is not covered by this guarantee. If the installation, assembly or care instructions that were valid at the time of installation are not followed or the product is used for a purpose other than that given in the written information the guarantee declaration does not apply. Problems caused by dirt, lime-scale or aggressive cleaners are not covered by the guarantee.
- F) The guarantee becomes void if repairs are not carried out competently or spare parts of non GROHE origin are used.
- G) Replaced parts become the property of GROHE and are to be surrendered to our service personnel or sent to our registered offices.

Please enter date of purchase and installation here.

### Our address

GROHE Limited  
1, River Road  
Barking,  
Essex, IG11 OHD  
GB  
Tel.: 0208 / 594 72 92  
Fax: 0208 / 594 88 98



© 2000 Friedrich Grohe AG & Co. KG

Friedrich Grohe AG & Co. KG · P.O. Box 1361 · 58653 Hemer/Germany  
Tel. (0) 23 72 / 93 - 0 · Fax: (0) 23 72 / 93 13 22