



Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,


- 1 - B 961721 XX
- 1a - B 961720 XX
- 2 - A 961157 XX
- 3 - A 861446 NU
- 4 - B 961660 NU
- 4a - B 961659 NU
- 5 - A 961625 XX
- 5a - B 961383 XX (BD284..)
- 6 - B 961155 NU




Ideal Standard

CERAPLAN

05.2021 / B565145




B D284 ..






B D247 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
<http://www.idealstandardinternational.com>





	P	bar		MIN. 0,1	MAX. 10		5	
	T	C		MIN. 0,1	MAX. 80		65	
							40	